


NOTE:

The Contractor is to check and verify all building and site dimensions, levels and sewer invert levels at connection points before work starts.

levels at connection points before work starts.
This drawing must be read with and checked against any structural or other specialist drawings provided.

The Contractor is to comply in all respects with the current Building Regulations whether or not specifically stated on these drawings. This drawing is not intended to show details of foundation or ground conditions. Each area of ground relied upon to support the structure depicted must be investigated by the Contractor and suitable methods of foundation be provided.



165 FLEET STREET

London

Title

LICENSING DRAWING

General Arrangement

BASEMENT

Project Manager/ Checked	Drawn By		Scale	Date	
	TH		1:100@A1	01/	/24
Arch./Des.	Drawing Number				Rev.