



Entry Point & Stacking Areas for Private Cars, Taxis & LGVs	Entry Points & Stacking Areas for HGV's, LGVs	—	Route to be kept clear of parked vehicles	No Entry to ALL vehicles
Exit Points for ALL Vehicles	No Exit to ALL vehicles	—	Controlled Loading / Unloading Areas	Emergency exit with CoLP agreement